Pegasus

www.pegasustech.net

Laser Barcode Scanner User Manual

Email ID:- mkt@pegasustech.net
support@pegasustech.net

Factory Default


Version V5.8

Introduction

This is a easily usemanualfor laser barcode scanner , if you need the moredetails about how to use ,please download from our official website or get the manual from distributors.

Installation

keyboard wedge cable install



keyboard wedge cable install


RS-232 Cable install

1.Turn off the power supply

2.Put the DB9 connector connection withthe device interface.


3.If the device (The 9th pin of serial)can not working , please connect the 5V power supply with cable.

4.Turn on the power .if the buzzer and LED light release the signal, so the the device is working normal.



RS-232 Cable install

USB Cable install (put the cable insert the USB serial directly, The Computer will detection and identification automatically



Accessories: Bracket install


1.Use the bracket connector connect to the main body of bracket.

2.Main body of bracket.

3.Philip's screw, Dimensions:M6*10MM

4.Base Support

5.Direct wedged in the base of bracket when the head of bracket and main body connection well.



Interface Choose

USB-HID Model*

Ps2-Keyboard Model

USB-COM Model

COM-RS232 Model

Scanning Type

Automatic successive scanning mode

Automatic flashing mode

Buzzer

Sound OFF

Sound ON

Barcode Display Tybe

Display barcode type after barcode

UN-Display type after barcode

Keyboard Model

Language Choice


USA


German


France

Keyboard Caps Lock control


Resume


Capitalize


Lower case

COM Model

Baud Rate


4800


9600


19200


38400


57600


115200

Prefix&Suffix Setting


AddPrefix


AddSuffix


Hide Before Character


Hide After Character

Special Code ON


CODE11


CODE 39


FULL ASCII


CODE 93


CODE 128


CODE 128ISBT


CODEBAR


Enable Interleaved 2 of 5


Industral 2 of 5


Matrix 2 of 5


CHINA POST CODE


MSI CODE


UPC-A


UPC-E


EAN-13


EAN-8

Suffix & Skip Setting


CR


LF


CR&LF


Tab


Space


None

Wireless Setting


RF Model


Delete Add

Setting DeviceADD

01

02

03

04

Pairs Add

Inventory Mode

Upload New Data

Upload All Data

Upload Statistic Data

Clear